



NOTES:

- 1. ATTACH THE GROUNDED SIDE OF THE POWER SUPPLY TO THE CONTROL CABINET GROUND TERMINAL.
- 2. MAINTAIN 1" MINIMUM SPACING BETWEEN CONDUITS IN CABINET BASE, CAP OR PLUG CONDUITS AT BOTH ENDS UNTIL USED.
- 3. IDENTIFY AND LABEL ALL FIELD TERMINALS.
- 4. GROUND CABINET WITH A $^{3}\prime_{4}{''}$ \times 10' COPPER COATED STEEL GROUND ROD PLACED IN A 1" PVC CONDUIT FOUNDATION SLEEVE.
- 5. PLACE ALL CONDUITS IN THE SAME TRENCH WHERE POSSIBLE.

OF TRANSPORTATION
OAD AND BRIDGE CONSTRUCTION
ECITY, UTAH Н UTAH DEPARTMENT OF Standard drawings for Road Salt Lake C TRAFFIC SIGNAL CONTROLLER BASE DETAIL

STD DWG

SECTION A-A

N-2007